get complete pdf at learnexams.com

Dell Client Advanced Exam | Questions and Answers| A Grade |2023/ 2024 Update

QUESTION
NIC Activity LED is off and Link indicator is green. This indicates NIC is connected to a valid network at its maximum port speed but data isn't being sent/received

Answer:
True

QUESTION
BOSS stands for:

Answer:
not Boot Optimized Server Subsystem

QUESTION
Which indicator shows whether power is present or a power fault has occurred in Precision Workstation systems?

learnexams

Answer:
not AC PSU LED

QUESTION
In a Precision Rack, one PSU is faulty and other one is fine. After hot plugging the new PSU, it starts to blink green and turns off. What do you think is the cause?

Answer:
PSU has Firmware/Voltage mismatch

LEARNEXAMS.COM

get complete pdf at learnexams.com

QUESTION
In a scenario where the System Board is replaced, remove the Processor Heatsink Module (PHM) together with the processor. There is no need to separate the PHM from the processor.

Answer:
True

QUESTION
DPK stands for

Answer:
Digital Product Key

QUESTION
The OEM Identity (ID) Module is a Utility used to replace the Dell Logo on the System Hardware like the Bezel

Answer:
False

learnexams

QUESTION
How many intrusion switches are there in Dell Precision Tower 7920?

Answer:
not 2

QUESTION
The BIOS can be accessed in a Dell System using which of the following keys:

Answer:
f2

LEARNEXAMS.COM